DUSTER HIGH PRESSURE DUST REMOVER

Duster immediately removes dust, paper chips, paper clips, dirt and many other micro particles from hard to reach areas on equipment. The blasting power removes the debris without leaving any residue.

GREAT FOR THESE APPLICATIONS

Keyboards Disk Drives
CD Drives CPU Housings
Printers Phones

Copy Machines Slot & Video Poker Machines Office & Computerized Equipment

Product Code: 2650-A

To Reorder Call (281) 647-9700 or
1-800-295-BETA

BETA TECHNOLOGY, INC. CORPORATE HEADQUARTERS P.O. BOX 218686 HOUSTON, TX 77218

EXCLUSIVELY FOR INDUSTRIAL & INSTITUTIONAL USE



HIGH PRESSURE DUST REMOVER

•BLAST AWAY

Paper Chips, Staples, Dust,

Paper Clips, Lint, Dirt
•I eaves No Residue

NET WT. 7 OZ.

DANGER:

EXTREMELY FLAMMABLE AEROSOL. CONTAINS GAS UNDER PRESSURE; MAY EXPLODE IF HEATED.

DIRECTIONS

Point nozzle toward surface to be cleaned. Hold upright and keep Duster 14 inches from the surface. Hold product above the keyboard keys, pointing spray down between the keys blowing the particles out. Spray Duster in quick short bursts.

DANGER

Extremely Flammable Aerosol. Contains gas under pressure; may explode if heated.

Keep away from heat, sparks, open flames, and hot surfaces.

-No smoking. Do not spray on an open flame or other ignition source. Pressurized container: Do not pierce or burn, even after use. Protect from sunlight. Do not expose to temperatures exceeding 50°C/122°F. Store in a well-ventilated place.

HMIS CODES: Health – 1; Flammability – 4; Reactivity – 0; Personal – A